


ARI2020 Bottom Outlet Ball Valve

INSPECTION & MAINTENANCE BULLETIN



These instructions are applicable to the following model:
ARI2020

Only facilities with AAR activity code C5 are certified to recondition, repair, retest, and qualify tank car vacuum relief valves. Personnel performing inspections and tests must be certified Level I per AAR Manual of Standards and Recommended Practices, M-1002, Appendix T, 1.4.3.

THE GREENBRIER COMPANIES
One Centerpointe Drive, Suite 200
Lake Oswego, Oregon 97035
info@gbrx.com

www.gbrx.com

THE
GREENBRIER
COMPANIES

July 27, 2023


New Valves for Replacement of Existing Equipment

New valves are tested, sealed and packaged at the time of manufacture. A new valve can be applied provided it is still in its original packaging.

Valve Rating

The ARI2020 Bottom Outlet Valve is rated to 100 psi and 300° F.

Disassembly Procedure



1. Remove the gasket (item #21) by inserting a flat screwdriver along the outer wall and prying underneath the gasket, taking care not to gouge or mar the metal surfaces.
2. The illustration above shows the valve open in the installed position. Turn the entire valve assembly over to continue disassembly.
3. Remove the two packing retainer bolts (item #12). Then remove the retainer (item #8) and the packing gland (item #7).
4. Remove the four cover bolts (item #17) from the cover (item #14). Then remove the cover.
5. Remove the cover gasket (item #15) taking care not to gouge or mar the metal surfaces.
6. Rotate the ball (item #2) to the closed position.
7. Lift the ball (item #2) out of the valve body (item #1) taking care not to gouge or mar the spherical surface.
8. Remove the stem (item #5) and the stem gasket (item #4) from the inside of the valve body. Remove the packing rings (item #6) from the outside of the valve body. The stem gasket and packing rings should be discarded and replaced with new components.
9. Remove the seal rings (item #16) and the spring washer (item #3) from the cover and body by using either a thin screwdriver or other sharp instrument taking care not to gouge or mar the metal surfaces.

Inspection of Valve Components

1. Remove the seal rings (item #4) and the spring washer (item #14) by using either a thin screwdriver or other sharp instrument taking care not to gouge, or mar the metal surfaces.
2. If necessary, clean the internal and external valve body (item #1) and the cover seal pockets with a light gauge wire brush.
3. Inspect the sealing surfaces on the body (item #1), cover (item #2), and stem (item #7) for signs of corrosion, voids, cracks, and scratches. These surfaces include the internal and external seal pockets of the body and cover, and the seal areas that the stem gasket (item #13) and packing rings (item #12) seal onto in the stem bore area. **NO DEFECTS ARE ALLOWED.**
4. Outside the sealing areas the defects must not exceed 1/16" in depth and 3/32" in width. Additionally, a maximum of one void per square inch is allowable, and the void area must not exceed 10% of total surface.
5. Clean the ball (item #3) with a commercial cleaning solution or in an ultrasonic bath to remove any residue.
6. Inspect the ball spherical surface for irregularities in the form of scratches or gouges. Scratches or gouges can be evaluated by sliding a fingernail over the affected area. If a fingernail "catches," the depth of the discontinuity could damage the ball seals (item #4) resulting in improper sealing of the valve. If any scratches fail the fingernail test, replace the ball (item #3) as it cannot be repaired.
7. Clean the valve body, cover, stem, and packing gland (item #11) with a commercial cleaning solution, or in an ultrasonic bath.
8. Bolts should be cleaned using a wire brush.

Reassembly

1. Insert a new spring washer (item #3) in the body (item #1) with the inside diameter edge facing upward toward the ball (item #2). Insert a seal (item #16) on top of the spring washer.
2. Slide the a new stem gasket (item #4) over the stem (item #5) and insert the stem into the body (item #1). Orient the stem (item #5) so that the slot in the ball (item #2) will engage the stem when inserted.
3. Carefully lower the ball (item #2) into the body cavity.
4. Inspect the seal (item #16) to ensure it remained seated in the seal groove.
5. Slide the packing rings (item #6) over the stem followed by the packing gland (item #7) and then the retainer (item #8). Apply a light coating of Bostik "NeverSeez" regular grade lubricant to the retainer bolts (item #12). Then apply the nuts and tighten evenly to 2 ft/lbs.
6. Apply a thin coating, not more than 1/32," of Nordstrom 555 sealant to the bottom surface of the second ball seal (item #16) then insert the seal into the cover (item #14) seat pocket. Do not apply excessive sealant as it could adversely affect the operation of the valve.
7. Install a new cover gasket (item #15).
8. Align the bolt holes in the cover (item #14) and valve body (item #1) then lower the cover into place taking care to ensure that the seal (item #16) does not slip out of position.
9. Apply a light coating of Bostik "NeverSeez" regular grade lubricant to the four bolts (item #17) and place them in the cover (item #14). Torque using a diametrically opposite (criss-cross) tightening sequence to 75 (+/- 5) ft/lbs.
10. Using an adjustable or open-end wrench, and avoiding quick or jerky movements, partially cycle the valve open and closed 6 to 8 times. Then cycle fully open and closed 3 times to seat the seals. Some resistance to rotation is normal.
11. Leave valve in the open position and install protective caps into both ports.

Testing

1. Apply a light coating of Bostik "NeverSeez" regular grade lubricant to the four bolts (item #17) and place them in the cover (item #14). Torque using a diametrically opposite (criss-cross) tightening sequence to 75 (+/- 5) ft/lbs.
2. Per the following procedure, air test the valve at both 50 and 100 psi. or as directed by the car owner using an approved Level III bubble leak test process. Any leakage is cause for rejection.

PROCEDURE

1. Apply appropriate adapter to test bench pod that will be used.
2. Select applicable gasket, and attach test item to test bench using all fasteners as per the design of the test item.
3. Ensure all fasteners are in place holding the test item to the test bench. Fasteners must be tool tight.
4. If applicable, cycle the valve from open to close three times to ensure valve is fully closed.
5. Pressurize test item to 100 psi. or as directed by the car owner.
6. Test item must hold at a SOAK time of a minimum of 10 minutes.
7. Apply leak test solution to possible leak paths based on test item type and configuration.
 - i. Such as, but not limited to:
 - a. Threaded Connections
 - b. Flanged Connections
 - c. Valve Stems must be tested with valve fully open and half open using a blind flange cover to test the stem packing area
 - d. Caps and Plugs
 - e. Valve seats
8. After leak test solution is applied to the test area/location, the solution DWELL time must be a minimum of 1 minute.
 - i. This is to mean that the solution must be applied to the area/location of test, and remain on the area at a minimum of 1 minute before the area can be observed for indications of leakage.
9. Observe for the formation of bubbles. Any continuous bubble formation within the allotted dwell time is cause for rejection.
10. Release pressure from the valve.
11. Blow the valve dry with compressed air.
12. Fully open valve and install a protective cap in the exposed end. Remove the test plate then remove the valve from the test fixture.
13. Turn the valve over and install a protective cap.
14. Spray the exterior surfaces with WD-40, or an equivalent lubricant to avoid oxidation.
15. Store the valve in a cardboard box or protective enclosure.
16. Record the results of the test on the appropriate form.
17. Mark and place the test item in the applicable areas.

The undertaking of repair or replacement by the Purchaser, or its agents, without the expressed written consent of The Greenbrier Companies (GBX) shall void the warranty and relieve GBX of all responsibility. Under no circumstances shall GBX be liable for any direct, incidental, consequential or other damages of any kind in connection with the installation, operation, maintenance, repair, inspection or other use of any product purchased from it.